




Press the ENTER key to enter the password input interface in the electrical parameter measurement interface , the default password 6666, press the ENTER key after the password input is confirmed. If the input correctly enters the parameter setting interface, if the input error returns to the display interface of the measurement parameters. Press the ENTER key to enter the parameter size of the modified state, and accompanied by the modification of the characters flashing, after the change is completed, press the ENTER key to confirm the parameters of the parameters can be changed , You can modify the next parameter, you can also leave the left side of the parameters of the modified state, return to the measurement interface.

When the user in the modified state of the parameters within 60 seconds without key operation will automatically return to the electrical parameters of the measurement display interface.

Factory default value

parameter	Display	Default	implication
Password protection	PASS	6666	Used to protect non-staff to modify
Wiring method	SYSS	3Ln3CT	Three-phase four-wire system , 2LL2CT and 2LL3CT Three-phase three-wire system
Voltage ratio	Pt_U	1	Voltage transformer ratio(1~9999)
current	Ct_I	1	Current transformer ratio(1~9999)
communication address	Adr	1	The address of the meter when the network is in communication 1~247
Baud rate	bAUd	9600	Communication Baud rate address1200~ 19200
Data forma	dAtA	81N	Data frame format : 8 data bits, a parity bit
backlight	BLt	1	units:minute ; If set to 0, the backlight will never go out; set to other values, the last time after the delay set the time off.
System data	dAtE	Current date	Such as : 2012.05.08
System time	tinE	Current time	Such as : 09:35:20
Electric energy clear	cLrEny	Cleared	Used to clear the energy parameters.
Firmware	VEr		The firmware version and date of the instrument



Set interface

5. communication

KPM10 three-phase multifunction power meter provides MODBUS-RTU communication protocol, a start, 8-bit data bits, 1/0 parity, 1/2 stop bits, each byte length of 11 bits.

Supported baud rates: 1200, 2400, 4800, 9600, 19200bps.

Factory default communication parameters: 9600, no parity, 1 stop bit.

RTU mode format for each byte:

1 start bit + 8 data bits + 1 parity bit + 1 stop bit

The format of the data frame is as follows:

Address field + Command field + Data field + CRC check area

Supported function codes			
DEC	HEX	definition	Operation description
01	0x01	Read relay output	Read one or more relay outputs
02	0x02	Read switch input	Read one or more switch input
03	0x03	Read register data	Read the value of one or more registers
05	0x05	Write a single relay output	Control all the way to close or disconnect the relay
16	0x10	Write multiple registers	Write multiple register data at a time

5.1 Relay output control and status read

This area stores the relay status. The user can read the current status using the Modbus protocol 01H function code and use the function code 05H to control the output.

Address	Parameter	Numerical range	Data type	Read-write property
0000H	Relay1(DO1)	1=ON,0=OFF	Bit	R/W

5.1.1 Read relay output status (function code 01H)

Addr	Fun	Start Reg hi	Start Reg lo	Reg Num hi	Reg Num lo	CRC16 hi	CRC16 lo
01H	01H	00H	00H	00H	01H	xxH	xxH

Response Data Frame: The slave responds to the host's data frame. (1 = ON, 0 = OFF), the lowest bit of the first byte is one of the lowest bits of the first byte. The first bit of the first byte is the lowest byte of the first byte. Address the relay state value, the rest of the order to the high order, useless bits filled with 0.

Read the contents of the digital output status response example.

Addr	Fun	Byte count	Data	CRC16 hi	CRC16 lo
01H	01H	01H	01H	90H	48H

Data byte content (Relay1 is closed)

Bit7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	0	0	0	0	0	0	1

5.1.2 Relay control (function code 05H)

Note that the control relay 0x00000 is the relay separated, 0 x FF00 means relay closed.

Request data frame

Addr	Fun	DO addr hi	DO addr lo	Value hi	Value lo	CRC16 hi	CRC16 lo
01H	05H	xx	xx	FFH	00H	xxH	xxH

Response data frame

Addr	Fun	DO addr hi	DO addr lo	Value hi	Value lo	CRC16 hi	CRC16 lo
01H	05H	xx	xx	FFH	00H	xxH	xxH

5.2 Read switch input status (function code 02H)

Query data frame: This function allows the user to obtain the status of the binary input DI ON / OFF (1 = ON, 0 = OFF). In addition to the slave address and the function field, the data frame needs to be included in the data field. The initial address and the number of DIs to be read.

The address of DI in KPM10 starts at 0000H (DI1 = 0000H, DI2 = 0001H ... and so on).

The binary input terminals DI1 to DI2 correspond to Bit0 to Bit1, respectively. The following example shows the state of the DI1 to DI2 read from the slave address 01

Addr	Fun	DI start reg hi	DI start reg lo	DI num hi	DI num lo	CRC16 hi	CRC16 lo
01H	02H	00H	00H	00H	04H	xx	xx

Response Number of Frames: The response contains the slave address, function code, number of data, packet and CRC check, each bit in the packet occupies one bit (1 = ON, 0 = OFF), the least significant bit of the first byte is the addressed DI1 value, the other is followed by the higher order, and the useless bit is filled with 0.

The following table shows an example of a read-through input (DI1 = ON, DI2 = ON) response.

Addr	Fun	Byte count	Data	CRC16 hi	CRC16 lo
01H	02H	01H	03H	E1H	89H

Data byte content

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	0	0	0	1	0	1	1

6. Common malfunction Analysis

- Nothing is displayed after the unit is powered on
  - Check if the supply voltage and other wiring are correct, also the supply voltage should be within the operating range
  - Turn off the device and the host computer, and then reboot
- The device is not working properly after power on
  - Turn off the device and the host computer, and then reboot
- Voltage or current readings incorrect
  - Check if the wiring mode setting matches the actual wiring mode
- Check whether the voltage transformer (PT) and current transformer (CT) ratio are set correctly

- Check if GND is grounded properly
- Check if the shield is grounded
- Check if the voltage transformer (PT) and current transformer (CT) are intact

- The power or power factor reading is incorrect, but the voltage and current readings are correct
  - Compare the voltage and current input of the actual wiring and wiring diagram, and check if the phase relationship is correct

- RS-485 communication is not working properly
  - Check whether the communication baud rate, ID and communication protocol settings of the host computer are consistent with the meter

- Please check the data bits, stop bits, parity settings and the host computer is consistent

- Check if the RS-232 / RS-485 converter is working properly
- Check if there are the problems in the entire communications network lines (Such as short circuit, open circuit, grounding, if the shield is properly grounded at one end, etc.)
- Turn off the device and the host computer, and then reboot
- If the communication line is longer, it is recommended to parallel connect a 100 ~200Ω matching resistors at the end of the communication line

**Note: If there are any unsolved problems, please contact our company's after-sales service department.**

7 Contact details

Henan Compere Smart Technology CO., LTD.

Telephone:+86-371-86181681

Fax:+86-371-67890037

Web:<http://www.compere-power.com/en/home/>

Address:No.41, Dongming Road, Zhengzhou, Henan Province, China

**The final interpretation of this manual is owned by Henan Compere Smart Technology Co.,Ltd.**