



## 5.4 Parameter settings

Parameter setting menu structure menu is as follows  
Factory default value:

No	Display	Default	Definition
1	CT_I	0001	Current transformer(1~9999)
2	Adr	001	Meter address(1~247)
3	bPS	9600	Baud rate (1200-19200bps)
4	dAIA	81E	Data format, 8 data bit, 1 parity bit, 1 stop bit
5	C_Eny	no	Used to clear energy data
6	PASS	6666	Avoid non-staff people to change meter settings
7	rCFg	no	Used to reconfigure wireless communication
8	rStM	no	Used to restart wireless module
9	C_SE	no	Used to clear paid left energy data
10	CTrM	rMod	Used to change relay control mode
11	rELy	on	Used to control relay on/off
12	F.Mod	n_P	Used to display meter forced power on/off mode
13	2.2.22.07.30		Display current firmware version

## 6 Communication

KPM33B supports MODBUS-RTU communication protocol, one start bit, 8-bit data bits, parity bit, 1 stop bits, each byte length is 11 bits.

Supported baud rates: 1200bps, 2400bps, 4800bps, 9600bps, 19200bps.

Factory default communication parameters: 9600bps, Even parity bit

1 start bit + 8 data bits + 1 parity bit + 1 stop bit

The format of the data frame is as follows:

Address field + command field + data field + CRC check field

Supported function codes			
DEC	HEX	Definition	Operation description
03	0x03	Read register data	Read the value of one or more registers
16	0x10	Write Multiple Registers	Write multiple register data at once

### 6.1 System parameters read and write

This area stores system parameters related to equipment operation, including communication parameters, current ratio, etc., which can be read by using the Modbus protocol 03H function code. or using the 10H function code setting.

Address	Parameter	Numerical range	Data type
0000H	Protection password	0~9999	Word
0001H	Modbus address	Modbus-RTU address: 1~247	Word
0002H	bps (BIT0~7): 0:1200, 1: 2400, 2: 4800, 3:9600, 4: 19200 Data frame (BIT 8~15): 0: 8, 1, n 1 : 8, 1, O, 2: 8, 1, e	1~9999	Word
000CH	Clear power	Enter 0x5578 command to clear the power immediately	

### 6.2 Basic measurement parameters Area

Basic measurement area, mainly measuring basic voltage, current, power, power factor, etc.;

All parameters in this area are real-time measurement parameters and are read using the Modbus protocol 03H function code, It is read-only data. The data form

## 9 Wireless communication

KPM33B supports WiFi wireless communication mode and can be connected to enterprise wireless AP. The uplink adopts mqtt protocol for data communication with the master station. The specific configuration steps are as follows:

Step 1: Set mobile hotspot

Set the WiFi hotspot account to compere-debug and the password to kpm-debug for the meter to connect. Then start the settings on Touch Energy APP.

Step 2: Set the meter to debug mode

Enter the setting interface, find the "rCFG:no" option and set it to "yes" mode.

rCFG:yes

Then the meter will initialize the network configuration.

**Note:** The system only stays in yes status for a few seconds then it will go back to no. Once u changed to yes status and pressed  key, the reconfigure step is finished.

The server configuration of both modes needs to use Touch Energy APP-meter setting function. The configuration steps are as follows:

Step 3: 'Touch Energy' APP meter setting

1. Download 'Touch Energy' from Google play or Apple store. As Fig 1.

2. Click 'Meter setting' to enter the code search page. As shown in Fig 2.

3. Search for devices: Input the production number to search if the number is wrong, the search button will be grayed and cannot be clicked. If the number is correct, click the "code search" button to identify the device.

4. Input the configuration parameters and submit:

4.1 Private server settings This page is for the meters sending data to the customers' private server.



Input private server address (support domain name and IP address), server port, MQTT account, MQTT password, etc. If using WiFi meter, the local WiFi name and Password are required. WPA2 for enterprise level WiFi can be set too. If using 4G meter, the WiFi name and Password is not required.

4.2 4G communication setting

Input server address (support domain name and IP address), port, MQTT account, MQTT password and submit. The default information is for sending data to T@ENERGY cloud platform.

at is floating-point data, and the data in this area is a real-time data on the primary side because it has been multiplied by the transformation ratio. This area is the real-time data on the primary side.

Address	Parameter	Data type	Unit
0030H	Phase A voltage	Floating point	V
0032H	Phase B voltage	Floating point	V
0034H	Phase C voltage	Floating point	V
0036H	Phase A current	Floating point	A
0038H	Phase B current	Floating point	A
003AH	Phase C current	Floating point	A
003CH	AB Line voltage	Floating point	V
003EH	BC Line voltage	Floating point	V
0040H	CA Line voltage	Floating point	V
0042H	Phase A active power	Floating point	W
0044H	Phase B active power	Floating point	W
0046H	Phase C active power	Floating point	W
0048H	Three phase active power	Floating point	W
004AH	Phase A reactive power	Floating point	var
004CH	Phase B reactive power	Floating point	var
004EH	Phase C reactive power	Floating point	var
0050H	Three phase reactive power	Floating point	var
0052H	Phase A apparent power	Floating point	VA
0054H	Phase B apparent power	Floating point	VA
0056H	Phase C apparent power	Floating point	VA
0058H	Three phase apparent power	Floating point	VA
005AH	Phase A power factor	Floating point	
005CH	Phase B power factor	Floating point	
005EH	Phase C power factor	Floating point	
0060H	Three phase power meter	Floating point	
0062H	Frequency	Floating point	Hz
0200H	Phase A apparent demand		
0200H	Phase B apparent demand		
0200H	Phase C apparent demand		

### 6.3 Multi rate area

All data in this area are cumulative amount of energy and they all belong to the primary side, which can be read using the Modbus protocol 03H function code.

Address	Parameter	Data type	Unit
0080H	Total active energy	Floating point	kWh
0082H	Forward active energy	Floating point	kWh
0084H	Reverse active energy	Floating point	kWh
0086H	Total reactive energy	Floating point	kvarh
0088H	Forward total reactive energy	Floating point	kvarh
008AH	Reverse total reactive energy	Floating point	kvarh
008CH	Total sharp active energy	Floating point	kWh
008EH	Total peak active energy	Floating point	kWh
0090H	Total flat active energy	Floating point	kWh
0092H	Total valley active energy	Floating point	kWh
0094H	Total sharp reactive energy	Floating point	kvarh
0096H	Total peak reactive energy	Floating point	kvarh
0098H	Total flat reactive energy	Floating point	kvarh
009AH	Total valley reactive energy	Floating point	kvarh
009CH	Total combined active energy for this month	Floating point	kWh
009EH	Total combined active energy of the previous 1 settlement day	Floating point	kWh
00A0H	Total combined active energy of the previous 2 settlement day	Floating point	kWh
00A2H	Total combined active energy of the previous 3 settlement day	Floating point	kWh
00A4H	Total combined active energy of the previous 4 settlement day	Floating point	kWh

### 4.3 WIFI communication setting

Input server address (support domain name and IP address), port, MQTT account, MQTT password, local WiFi name and password (WPA2 for enterprise level WIFI can be set too) and submit.

The default information is for sending data to

T@ENERGY cloud platform.

5. Wait for about 20 seconds for the meter to return status information.

If the configuration is successful, it will display "Successfully issued, please continue", click 'exist' to return to the device ID search interface.

Click "next" for bulk quantity meters settings. It will enter the last setting page and retain the data set last time. Users only need to change the meter number and submit.

### FAQ for network connection

1. Issuing timeout: data communication timeout. It means the settings are not successfully or setting is succeeded but data return is failed.

Solution: Click 'OK' to stay on the device information page and wait for 30 seconds to see if the device is showing offline. If yes (offline), that means the setting is succeeded. If not (online), pls submit again.

2. Parameter lost: Data lost during communication. Solution: Click 'OK' to stay on the device information page and wait for 30 seconds to see if the device is showing offline. If yes (offline), that means the setting is succeeded. If not (online), pls submit again.

### 10 Common Failure Analysis

#### No display after device is powered on

- Check whether the power supply voltage and other wiring are correct, and the power supply voltage should be within the working range;
- Turn off the device and host computer, and then restart.

#### The device does not work properly after power-on

- Turn off the device and host computer, and then restart.

#### Incorrect voltage or current reading

- Check whether the wiring mode setting is consistent with the actual wiring method

#### The power or power factor is incorrect, but the voltage and current is correct

- Compare the voltage and current input of the actual wiring and the wiring diagram, and check whether the phase relationship is correct

#### RS-485 communication is abnormal

- Check whether the communication baud rate, ID and communication protocol settings of the host computer are consistent with the device; Please check whether the data bit, stop bit, check bit settings are consistent with the host computer

## 11 Product Quality Assurance

### 11.1 Quality Assurance

All new devices sold to users, within a certain number of years from the date of sale to users, are subject to free quality assurance for failures caused by defects in design, materials and workmanship. If the product is determined to meet the above warranty conditions, the supplier will repair and replace it free of charge.

The supplier may require the user to send the device back to the manufacturer to confirm whether the device is covered by the free warranty and repair the device.

00A6H	Total combined active energy of the previous 5 settlement day	Floating point	kWh
00A8H	Total combined active energy of the previous 6 settlement day	Floating point	kWh
00AAH	Total combined active energy of the previous 7 settlement day	Floating point	kWh
00ACH	Total combined active energy of the previous 8 settlement day	Floating point	kWh
00AEH	Total combined active energy of the previous 9 settlement day	Floating point	kWh
00B0H	Total combined active energy of the previous 10 settlement day	Floating point	kWh
00B2H	Total combined active energy of the previous 11 settlement day	Floating point	kWh
00B4H	Total combined active energy of the previous 12 settlement day	Floating point	kWh
00B6H	Total combined reactive energy for this month	Floating point	kvarh
00B8H	Total combined reactive energy of the previous 1 settlement day	Floating point	kvarh
00BAH	Total combined reactive energy of the previous 2 settlement day	Floating point	kvarh
00BCH	Total combined reactive energy of the previous 3 settlement day	Floating point	kvarh
00BEH	Total combined reactive energy of the previous 4 settlement day	Floating point	kvarh
00C0H	Total combined reactive energy of the previous 5 settlement day	Floating point	kvarh
00C2H	Total combined reactive energy of the previous 6 settlement day	Floating point	kvarh
00C4H	Total combined reactive energy of the previous 7 settlement day	Floating point	kvarh
00C6H	Total combined reactive energy of the previous 8 settlement day	Floating point	kvarh
00C8H	Total combined reactive energy of the previous 9 settlement day	Floating point	kvarh
00CAH	Total combined reactive energy of the previous 10 settlement day	Floating point	kvarh
00CCH	Total combined reactive energy of the previous 11 settlement day	Floating point	kvarh
00CEH	Total combined reactive energy of the previous 12 settlement day	Floating point	kvarh
00D0H	Sharp active energy for this month	Floating point	kWh
00D2H	Sharp active energy of the previous 1 settlement day	Floating point	kWh
00D4H	Sharp active energy of the previous 2 settlement day	Floating point	kWh
00D6H	Sharp active energy of the previous 3 settlement day	Floating point	kWh
00D8H	Sharp active energy of the previous 4 settlement day	Floating point	kWh
00DAH	Sharp active energy of the previous 5 settlement day	Floating point	kWh
00DCH	Sharp active energy of the previous 6 settlement day	Floating point	kWh
00DEH	Sharp active energy of the previous 7 settlement day	Floating point	kWh
00E0H	Sharp active energy of the previous 8 settlement day	Floating point	kWh
00E2H	Sharp active energy of the previous 9 settlement day	Floating point	kWh
00E4H	Sharp active energy of the previous 10 settlement day	Floating point	kWh
00E6H	Sharp active energy of the previous 11 settlement day	Floating point	kWh
00E8H	Sharp active energy of the previous 12 settlement day	Floating point	kWh
00EAH	Sharp reactive energy for this month	Floating point	kvarh
00ECH	Sharp reactive energy of the previous 1 settlement day	Floating point	kvarh
00EEH	Sharp reactive energy of the previous 2 settlement day	Floating point	kvarh
00F0H	Sharp reactive energy of the previous 3 settlement day	Floating point	kvarh
00F2H	Sharp reactive energy of the previous 4 settlement day	Floating point	kvarh
00F4H	Sharp reactive energy of the previous 5 settlement day	Floating point	kvarh
00F6H	Sharp reactive energy of the previous 6 settlement day	Floating point	kvarh
00F8H	Sharp reactive energy of the previous 7 settlement day	Floating point	kvarh
00FAH	Sharp reactive energy of the previous 8 settlement day	Floating point	kvarh
00FCH	Sharp reactive energy of the previous 9 settlement day	Floating point	kvarh
00FEH	Sharp reactive energy of the previous 10 settlement day	Floating point	kvarh
0100H	Sharp reactive energy of the previous 11 settlement day	Floating point	kvarh
0102H	Sharp reactive energy of the previous 12 settlement day	Floating point	kvarh
0104H	Peak active energy for this month	Floating point	kWh
0106H	Peak active energy of the previous 1 settlement day	Floating point	kWh
0108H	Peak active energy of the previous 2 settlement day	Floating point	kWh
010AH	Peak active energy of the previous 3 settlement day	Floating point	kWh
010CH	Peak active energy of the previous 4 settlement day	Floating point	kWh
010EH	Peak active energy of the previous 5 settlement day	Floating point	kWh
0110H	Peak active energy of the previous 6 settlement day	Floating point	kWh
0112H	Peak active energy of the previous 7 settlement day	Floating point	kWh

0114H	Peak active energy of the previous 8 settlement day	Floating point	kWh
0116H	Peak active energy of the previous 9 settlement day	Floating point	kWh
0118H	Peak active energy of the previous 10 settlement day	Floating point	kWh
011AH	Peak active energy of the previous 11 settlement day	Floating point	kWh
011CH	Peak active energy of the previous 12 settlement day	Floating point	kWh
011EH	Peak reactive energy of this month	Floating point	kvarh
0120H	Peak reactive energy of the previous 1 settlement day	Floating point	kvarh
0122H	Peak reactive energy of the previous 2 settlement day	Floating point	kvarh
0124H	Peak reactive energy of the previous 3 settlement day	Floating point	kvarh
0126H	Peak reactive energy of the previous 4 settlement day	Floating point	kvarh
0128H	Peak reactive energy of the previous 5 settlement day	Floating point	kvarh
012AH	Peak reactive energy of the previous 6 settlement day	Floating point	kvarh
012CH	Peak reactive energy of the previous 7 settlement day	Floating point	kvarh
012EH	Peak reactive energy of the previous 8 settlement day	Floating point	kvarh
0130H	Peak reactive energy of the previous 9 settlement day	Floating point	kvarh
0132H	Peak reactive energy of the previous 10 settlement day	Floating point	kvarh
0134H	Peak reactive energy of the previous 11 settlement day	Floating point	kvarh
0136H	Peak reactive energy of the previous 12 settlement day	Floating point	kvarh
0138H	Flat active energy for this month	Floating point	kWh

## 7 Common malfunction analysis

➤ Nothing is displayed after the unit is powered on

- Check that the supply voltage and other wiring are correct and that the supply voltage should be within the operating range
- Turn off the device and the host computer, and then reboot

➤ The device is not working properly after power on

- Turn off the device and the host computer, and then reboot

➤ Voltage or current readings incorrect

- Check if the wiring mode setting matches the actual wiring mode

- Check whether the voltage transformer (PT), current transformer (CT) ratio is set correctly

- Check that GND is properly grounded

- Check that GND is properly grounded

- Check that the shield is grounded

- Check the voltage transformer (PT), current transformer (CT) is intact

➤ The power or power factor reading is incorrect, but the voltage and current readings are correct

- Comparison of the actual input voltage and current wiring and wiring diagram, to check whether the correct phase relationship

➤ RS-485 communication is not normal

- Check whether the communication baud rate, ID and communication protocol settings of the host computer are consistent with the meter

- Please check the data bits, stop bits, parity settings and the host computer is consistent

- Check that the RS-232 / RS-485 converter is working properly

- Check whether the problem entire communications network lines (short circuit, open circuit, grounding, shielding in a single properly grounded, etc.)

- Turn off the device and the host computer, and then reboot
- The communication line length is recommended to connect approximately 100 to 200 ohm matching resistors at the end of the communication line

Note: If there are some unsolved problems, please contact our company's after-sales service department

## 8 Product quality

### 8.1 Quality assurance

For all new devices sold to users, within a certain number of years from the date of sale to users, free quality assurance will be implemented for failures caused by defects in design, materials and workmanship. If the product is determined to meet the above warranty conditions, the supplier will repair and replace it free of charge.

### 8.2 Quality assurance limited

Remarks: Damage caused by incorrect installation, use, and storage is not covered by the warranty.

## 11.2 Warranty Restrictions

The following devices are not covered by the free warranty:

- Damage caused by incorrect installation, use, and storage.

- Abnormal operation and application conditions beyond the product specifications.

- Devices repaired by organizations or persons not authorized by the company.

- Devices that have exceeded the free warranty period.

## 12 Contact Details

Henan Compere Smart Technology CO., LTD.

Telephone: +86-371-86181681

Fax: +86-371-67890037

Web: www.comperepower.com

Address: No.41, Dongming Road, Zhengzhou, Henan Province, China

The final interpretation of this manual is owned by Henan Compere Smart Technology Co., Ltd.