
UNFOLD

1 | UNFOLD Remove the Yurt tent from the hand bag and unfold the frame.




2 | POSITIONING Make sure the canopy is above and the legs are below



3 | TIGHTEN VALVES

It is with 3 pcs inflate / deflate valves and 1 pcs overpressure valves. Tighten the valves.








INFLATING

4 | INFLATING

Insert the electric pump into the opened inflate / deflate valve and inflating the one leg

ABOUT THE PRESSURE

Inflate untill the tube feels very solid (3PSI/0.2BAR). The remaining air will escape through the overpressure valve.











POSITIONING

5 | POSITIONING LEGS

Drive 8 stakes into the ground at an angle of 40 degrees . When you cannot use stakes on solid ground , you can buckle 4 water barrels to the 4 legs .






Sand or snow

Grass

Grass

Solid Ground








REPLACE THE CANOPY


6 | REMOVE THE OLD CANOPY

Torn the velcros of leg bottoms and the velcros of the inflate/deflate valves, open the middle buckles, remove the old canopy



7 | INSTALL THE NEW CANOPY,

Sticky the velcros of leg bottoms and the velcros of the inflate/deflate valves, close the middle buckles, install the new canopy





DEFLATE

FOLDING & STORAGE


8 | DEFLATE


Deflate Yurt tent by opening the 3 inflation valves. Do not remove the overpressure valves




10 | STORAGE


Do not storage the Yurt tent when it's wet. Hang both frame and cloths in a dry environment.















DO'S AND DONT'S

cleaning

when it's wet



Do not use sharp objects

Do not use chemicals for

Do not use near an open

fire or heated objects



Can be used till 6 bft.






Pressure (3PSI/0.2 BAR)



Anchor with stakes on soft ground



Anchor with water barrels on hard ground

NEVER LEAVE THE YURT TENT UNATTENDED AND TAKE CARE OF YOUR **BELONGINGS**


AFTER USE OF THE YURT TENT ONE STORE IT IN A DRY PLACE Never store a wet tent. Hang out all the canopy and the leg frame in a dry and warm place.

CLEANING


Only use water with a soft handbrush and a wet cloth to clean the tent. Do not use any cleaning products.

PARTS

Canopy 1x



Leg frame(cover+TPU bladder) 1x



TPU repair 2x



Rope 4x



Inflate/deflate valves 3x+1 spare valves



Overpressure valves 1x+1 spare valves



Stakes

8x

ACCESSORIES OPTIONAL


Hand bag



Water barrel




Hook for zipper



Electrical pump

Screw stakes

U shape fork



PROMOTIONA VIDEO



