
UNFOLD

1 | UNFOLD Remove the Spider tent from the carry bag and unfold the frame.




2 | POSITIONING Make sure the canopy is above and the legs are below



3 | TIGHTEN VALVES

It is with 11 pcs inflate / deflate valves and 8 pcs overpressure valves. Tighten the valves.








INFLATING


4 | INFLATING


Insert the electric pump into the opened inflate / deflate valve and inflating each frame pole separately.




ABOUT THE PRESSURE

Inflate untill the tube feels very solid (3PSI/0.2BAR). The remaining air will escape through the overpressure valve.


























POSITIONING

5 | POSITIONING LEGS

Drive 8 stakes into the ground at an angle of 40 degrees. When you cannot use stakes on solid ground, you can buckle 4 water barrels to the 4 legs.





Sand or snow



Solid Ground

Grass











REPLACE THE CANOPY


6 | REMOVE THE OLD CANOPY Remove the old canopy and pull down the zipper from top to bottom



7 | INSTALL THE NEW CANOPY,
Put the new canopy on,
pull the zipper from bottom to top



ZIPPERS



DEFLATE

FOLDING & STORAGE


8 | DEFLATE


Deflate Spider tent by opening the 11 inflation valves. Do not remove the overpressure valves


9 | FOLD


10 | STORAGE


Do not storage the Spider tent when it's wet. Hang both frame and cloths in a dry environment.















DO'S AND DONT'S

cleaning



Do not use sharp objects

Do not use chemicals for

Do not use near an open

fire or heated objects

tent when it's wet

Do not store the Spider



Can be used till 6 bft.





Pressure (3PSI/0.2 BAR)



Anchor with stakes on soft ground



Anchor with water barrels on hard ground

NEVER LEAVE THE Spider TENT UNATTENDED AND TAKE CARE OF YOUR **BELONGINGS**

AFTER USE OF THE Spider TENT ONE STORE IT IN A DRY PLACE Never store a wet tent. Hang out all the canopy and the leg frame in a dry and warm place.


CLEANING

Only use water with a soft handbrush and a wet cloth to clean the tent. Do not use any cleaning products.

PARTS


Canopy 1x

Leg frame(cover+TPU bladder) 1x



Rope

4x




TPU repair 2x



Sand bag 4x








Overpressure valves 8x+1 spare valves



Hand pump



Stakes 8x




ACCESSORIES OPTIONAL


Carry bag




Water barrel



Electrical pump



Hook for zipper



Screw stakes

U shape fork



